

Preface

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

Version 2.0

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Trademark Recognition

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corp.

MMX, Pentium, Pentium-II, Pentium-III, Celeron are registered trademarks of Intel Corporation.

Other product names used in this manual are the properties of their respective owners and are acknowledged.

Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment onto an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Shielded interconnect cables and a shielded AC power cable must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

Safety Instructions

Your system is designed and tested to meet the latest standards of safety for information technology equipment. However, to ensure your safety, it is important that you read the following safety instructions.

Setting up your system

- Read and follow all instructions in the documentation before you operate your system.
- Do not use this product near water or a heated source such as a radiator.
- Set up the system on a stable surface.
- Openings on the chassis are for ventilation. Do not block or cover these openings. Make sure you leave plenty of space around the system for ventilation. Never insert objects of any kind into the ventilation openings.
- Use this product in environments with ambient temperatures between 0°C and 40°C.
- If you use an extension cord, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed its ampere rating.

Attention during use

- Do not step on the power cord or let anything rest on top of it.
- Do not spill water or any other liquid on your system.
- When the system is turned OFF, a small amount of electrical current still flows. Always unplug all power, modem, and network cables from the power outlets before cleaning the system.

- If you encounter the following technical problems with the product, unplug the power cord and contact a qualified service technician or your retailer.
 - The power cord or plug is damaged.
 - Liquid has been spilled into the system.
 - The system does not function properly even if you follow the operating instructions.
 - The system was dropped or the cabinet is damaged.
 - The system performance changes.



The warranty does not apply to products that have been disassembled by users.

Safety cautions and warnings

Optical Drive Safety Information

Optical drive sold with this system contains a CLASS 1 LASER PRODUCT.



CAUTION:

Invisible laser radiation when open. Do not stare into beam or view directly with optical instructions.

WARNING:

Making adjustments or performing procedures other than those specified in the user's manual may result in hazardous laser exposure. Do not attempt to disassemble the optical drive. For your safety, have the optical drive serviced only by an authorized service provider.

Product disposal notice



IMPORTANT:

This symbol if the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

Nordic Lithium Cautions (for lithium-ion batteries)



CAUTION:

Danger of explosion if battery is incorrectly replaced only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Product disposal notice



1. Do not place this product underneath heavy loads or in an unstable position.

2. Do not use or expose this product around magnetic fields as magnetic interference may affect the performance of the product.

3. Do not expose this product to high levels of direct sunlight, high-humidity or wet conditions.

4. Do not block the air vents to this product or impede the airflow in any way.

Canadian Department of Communications

This class B digital apparatus meets all requirements of the Canadian Interference-causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

About the Manual

The manual consists of the following:

Chapter 1 Introducing the PC	Describes features of the PC. ⇒ page 1
Chapter 2 Using BIOS	Provides information on using the BIOS Setup Utility. ⇒ page 9
Chapter 3 Using the Motherboard Software	Describes the motherboard software. ⇒ page 39
Chapter 4 Troubleshooting	Provides basic trouble shooting tips. ⇒ page 51

TABLE OF CONTENTS

Preface	i
Chapter 1	1
Introducing the PC	1
Introduction.....	1
Specifications.....	2
Front and Rear I/O.....	4
Motherboard Components.....	6
Header Pin Definition	8
Chapter 2	9
Using BIOS	9
About the Setup Utility.....	9
<i>The Standard Configuration.....</i>	<i>10</i>
<i>Entering the Setup Utility.....</i>	<i>10</i>
<i>Resetting the Setup Utility.....</i>	<i>11</i>
Using BIOS.....	12
BIOS Navigation Keys.....	13
Main Menu.....	14
Advanced Menu.....	15
Chipset Menu.....	27
Tweak Menu.....	29
Boot Menu.....	32
Security Menu.....	34
Exit Menu.....	36
Updating the BIOS.....	38

Chapter 3	39
Using the Motherboard Software	39
Installing the Windows OS.....	39
Drivers auto-installing under Windows 8.1.	40
<i>Running Setup</i>	41
Manual Installation.....	44
Windows 8.1 OS Recovery.....	46
 Chapter 4	 51
Troubleshooting	51
Troubleshooting and problem solution.....	51

Chapter 1

Introducing the PC

Introduction

Thank you for choosing **LIVA X Mini PC** featuring BAT-MINI2 of great performance and with stylish and flexible design.

This mini PC is based on Intel® Bay Trail-M platform. This latest Celeron processor is a multi-core system-on-a-chip (SoC) that integrates the next generation Intel® processor core, graphics, memory, and I/O interfaces into one solution. One mini PCIE slot and one mSATA slot are for extending usage. It implements one USB 3.0 port and two USB 2.0 ports at the front panel.

It supports DDR3L up to 4 GB single channel soldered down memory , a direct soldered down eMMC up to 32/64GB storage. It also can add additional storage from mSATA SSD and USB flash drive.

The system is equipped with a set of I/O ports at the rear panel, including one DC_IN port (12V), one HDMI port, one RJ45 LAN connector, one Audio combo jack, one VGA port.



*Note:
ID design and specification may vary, please refer
to actual goods you purchase.*

Specifications


CPU/Chipset	<ul style="list-style-type: none"> Intel® Bay Trail-M SoC
Memory	<ul style="list-style-type: none"> 4GB/2GB DDR3L - Single channel DDR3L soldered down memory
Expansion Slots	<ul style="list-style-type: none"> 1 x mini PCIE slot 1 x mSATA slot <p>(one supports half-card for wireless card, the other supports full-card for mSATA SSD)</p>
Storage	<ul style="list-style-type: none"> Direct soldered down eMMC 32/64GB Additional storage from mSATA SSD and USB flash drive

Audio	<ul style="list-style-type: none"> Realtek ALC283 <ul style="list-style-type: none"> - 2 Channel High Definition Audio Codec - 3.5 mm jack with stereo sound and mic (combo) supports for jack detection
LAN	<ul style="list-style-type: none"> Realtek RTL8111G-CG Gigabit LAN <ul style="list-style-type: none"> - 10/100/1000 Fast Ethernet Controller
Rear Panel I/O	<ul style="list-style-type: none"> 1 x DC_IN port (12V only) 1 x HDMI port 1 x RJ45 LAN connector 1 x Audio combo jack 1 x VGA port
Internal I/O Connectors & Headers	<ul style="list-style-type: none"> 1 x 2-pin battery connector 2 x mini PCIE slots 1 x power button 1 x System LED header 1 x UART Debug header
System BIOS	<ul style="list-style-type: none"> AMI BIOS with 64Mb SPI Flash ROM Support dual display (depends on display output)
OS Support	<ul style="list-style-type: none"> Windows 7*/Windows 8.1 <ul style="list-style-type: none"> *Note: Windows 7 is only supported by mSATA storage device. Windows 8.1 with Bing pre-loaded* <ul style="list-style-type: none"> *Note: OS pre-installation is subject to certain product.
Power Adapter	<ul style="list-style-type: none"> APD WA-36A12 <ul style="list-style-type: none"> -12V/ 3A/ 36W DC Adapter
Dimension	<ul style="list-style-type: none"> 135 x 83 x 40mm

**WARNING:**


Please realize that there is a certain risk involved with overclocking, including adjusting the setting in the BIOS, or using the third-party overclocking tools. Overclocking may affect your system stability, or even cause damage to the components and devices of your system. It should be done at your own risk and expense. We are not responsible for possible damage caused by overclocking.

Front and Rear I/O

**Note:**

ID design and specification may vary, please refer to actual goods you purchase.

- | | |
|-------------------------|---|
| 1. Power Button | Use this button to power on/off the system. |
| 2. USB 2.0 Ports | Use the USB 2.0 port to connect USB 2.0 device. |
| 3. USB 3.0 Port | Use the USB 3.0 port to connect USB 3.0 device. |

**4. 12V DC_IN Port**

Connect the DC_IN port to the power adapter.

5. HDMI Port

You can connect the display device to the HDMI port.

6. LAN Port

Connect an RJ-45 jack to the LAN port to connect your computer to the Network.


7. Combo Audio Jack
(Line out & Mic in)

It is used to connect a microphone* or speaker.

8. VGA Port

Connect your monitor to the VGA port.

Motherboard Components







Table of Motherboard Components


LABEL	COMPONENTS
1. Memory 1~4	Single channel DDR3L soldered down memory
2. SYS_LED	System power LED
3. POWER_BTN	Power On/Off button
4. MINI_PCIE	Mini PCIE supports wireless card
5. UART_DBG	UART debug header
6. eMMC	Direct soldered down 32/64GB eMMC
7. BT	Battery connector
8. CPU	Bay Trail-M SoC
9. MSATA	mSATA supports mSATA SSD

Header Pin Definition

UART_DBG



BT (Battery)



Chapter 2

Using BIOS

About the Setup Utility

The computer uses the latest “American Megatrends Inc. ” BIOS with support for Windows Plug and Play. The CMOS chip on the motherboard contains the ROM setup instructions for configuring the motherboard BIOS.

The BIOS (Basic Input and Output System) Setup Utility displays the system’s configuration status and provides you with options to set system parameters. The parameters are stored in battery-backed-up CMOS RAM that saves this information when the power is turned off. When the system is turned back on, the system is configured with the values you stored in CMOS.

The BIOS Setup Utility enables you to configure:

- Hard drives, diskette drives and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power Management features

The settings made in the Setup Utility affect how the computer performs. Before using the Setup Utility, ensure that you understand the Setup Utility options.

This chapter provides explanations for Setup Utility options.

The Standard Configuration

A standard configuration has already been set in the Setup Utility. However, we recommend that you read this chapter in case you need to make any changes in the future.

This Setup Utility should be used:

- when changing the system configuration
- when a configuration error is detected and you are prompted to make changes to the Setup Utility
- when trying to resolve IRQ conflicts
- when making changes to the Power Management configuration
- when changing the password or making other changes to the Security Setup

Entering the Setup Utility

When you power on the system, BIOS enters the Power-On Self Test (POST) routines. POST is a series of built-in diagnostics performed by the BIOS. After the POST routines are completed, the following message appears:

Press DEL to enter SETUP

Press the delete key to access BIOS Setup Utility.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.	
Main	Advanced Chipset Tweak Boot Security Exit
BIOS Information System Language [English] System Date [Tue 10/28/2014] System Time [11:16:31]	
Choose the system default language → ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.	

Resetting the Default CMOS Values

When powering on for the first time, the POST screen may show a “CMOS Settings Wrong” message. This standard message will appear following a clear CMOS data at factory by the manufacturer. You simply need to Load Default Settings and Save it to reset the default CMOS values.

Note: Changes to system hardware such as different CPU, memories, etc. may also trigger this message.



Using BIOS

When you start the Setup Utility, the main menu appears. The main menu of the Setup Utility displays a list of the options that are available. A highlight indicates which option is currently selected. Use the cursor arrow keys to move the highlight to other options. When an option is highlighted, execute the option by pressing <Enter>.

Some options lead to pop-up dialog boxes that prompt you to verify that you wish to execute that option. Other options lead to dialog boxes that prompt you for information.

Some options (marked with a triangle ►) lead to submenus that enable you to change the values for the option. Use the cursor arrow keys to scroll through the items in the submenu.

In this manual, default values are enclosed in parenthesis. Submenu items are denoted by a triangle ►.



The default BIOS setting for this motherboard apply for most conditions with optimum performance. We do not suggest users change the default values in the BIOS setup and take no responsibility to any damage caused by changing the BIOS settings.

BIOS Navigation Keys

The BIOS navigation keys are listed below:

KEY	FUNCTION
ESC	Exits the current menu
↑↓→←	Scrolls through the items on a menu
+/-	Change Opt.
Enter	Select
F1	General Help
F2	Previous Value
F3	Optimized Defaults
F4	Save & Exit



For the purpose of better product maintenance, the manufacture reserves the right to change the BIOS items presented in this manual. The BIOS setup screens shown in this chapter are for reference only and may differ from the actual BIOS. Please visit the manufacture's website for updated manual.

Main Menu

When you enter the BIOS Setup program, the main menu appears, giving you an overview of the basic system information. Select an item and press <Enter> to display the submenu.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.	
Main	Advanced Chipset Tweak Boot Security Exit
BIOS Information	Choose the system default language.
System Language [English]	
System Date [Tue 10/28/2014]	
System Time [11:16:31]	
	→ ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.	

System Language (English)


This item is used to set system language.

System Date & Time

The Date and Time items show the current date and time on the computer. If you are running a Windows OS, these items are automatically updated whenever you make changes to the Windows Date and Time Properties utility.

Advanced Menu

The Advanced menu items allow you to change the settings for the CPU and other system.



► LAN Configuration

The item in the menu shows the LAN-related information that the BIOS automatically detects.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Advanced		
LAN Configuration		Enabled/Disabled
Onboard LAN Controller	[Enabled]	Onboard LAN 1 Controller
		→ ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

Onboard LAN Controller (Enabled)

Use this item to enable or disable Onboard LAN 1 controller.

Press <Esc> to return to the Advanced Menu page.

►Power Management Setup

This page sets up some parameters for system power management operation.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Advanced		
Power Management Setup		About Resume by PCI/PCI-E/LAN/ Ext .USB3.0 PME
Resume By PME	[Disabled]	→ ← :Select Screen ↑ ↓ :Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit
Resume By USB	[Enabled]	
Resume By RTC Alarm	[Disabled]	
EUP Function	[Enabled]	
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

Resume By PME (Disabled)

This item specifies whether the system will be awakened from power saving modes when activity or input signal of the specified hardware peripheral or components is detected.

Resume By USB (Enabled)

This item allows you to enable/disable the USB device wakeup function from S3 mode.

Resume By RTC Alarm (Disabled)

The system can be turned off with a software command. If you enable this item, the system can automatically resume at a fixed time based on the system's RTC (realtime clock). Use the items below this one to set the date and time of the wakeup alarm. You must use an ATX power supply in order to use this feature.

EUP Function (Enabled)

This item allows user to enable or disable EUP support.

Press <Esc> to return to the Advanced Menu page.

► PCI Express Configuration

This page sets up PCI Express configuration.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.	
Advanced	
PCI Express Configuration mPCIe Speed [Auto]	Configure PCIe slot speed → ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.	


mPCIe Speed [Auto]

This item allows user to configure the mPCIe speed.

Press <Esc> to return to the Advanced Menu page.

► ACPI Configuration

The item in the menu shows the highest ACPI sleep state when the system enters suspend.



ACPI Sleep State [S3(Suspend to RAM)]

This item allows user to enter the ACPI S3 (Suspend to RAM) Sleep State (default).

Press <Esc> to return to the Advanced Menu page.

► CPU Configuration

The item in the menu shows the CPU Configuration.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Advanced		
CPU Configuration		Socket sepcific CPU Information
► Socket 0 CPU Information		
CPU Speed	1.58 GHz	→ ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
64-bit	Supported	
Limit CPUID Maximum	[Disabled]	
Execute Disable Bit	[Enabled]	
Intel Virtualization Technology	[Enabled]	
Power Technology	[Energy Efficient]	
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

► Socket 0 CPU Information

Scroll to this item and press <Enter> and view the following screen:

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Advanced		
Socket 0 CPU Information		
Intel(R) Celeron(R) CPU N2808 @ 1.58GHz		
CPU Signature	30678	
Microcode Patch	815	
Max CPU Speed	1584 MHz	
Min CPU Speed	500 MHz	
Processor Cores	2	
Intel HT Technology	Not Supported	
Intel VT-x Technology	Supported	
L1 Data Cache	24 KB x 2	
L1 Code Cache	32 KB x 2	
L2 Cache	1024 KB x 1	
L3 Cache	Not Present	
		→ ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

Intel(R) Celeron(R) CPU N2808 @ 1.58GHz

This is display-only field and displays the information of the CPU installed in your computer.

CPU Signature (30678)

This item shows the information of the CPU signature.

Microcode Patch (815)

This item shows the version of microcode patch.

Max CPU Speed (1584 MHz)

This item shows the max speed of the CPU.

Min CPU Speed (500 MHz)

This item shows the min speed of the CPU.

Processor Cores (2)

This item shows the number of cores of the processor.

Intel HT Technology (Not Supported)

This item shows the computer supports Intel HT technology or not.

Intel VT-X Technology (Supported)

This item shows the computer supports Intel VT-X technology or not.

L1 Data Cache (24 KB x 2)

This item shows the size of CPU L1 Data Cache memory.

L1 Code Cache (32 KB x 2)

This item shows the size of CPU L1 Code Cache memory.

L2/L3 Cache (1024 KB x 1/Not Present)

These items show the size of CPU L2/L3 Cache memory.

Press <Esc> to return to the CPU Configuration page.

CPU Speed (1.58 GHz)

This item shows the processor speed.

64-bit (Supported)

This item shows the computer supports EMT64.

Limit CPUID Maximum (Disabled)

Use this item to enable or disable the maximum CPUID value limit, you can enable this item to prevent the system from “rebooting” when trying to install Windows NT 4.0.

Excute Disable Bit (Enabled)

This item allows the processor to classify areas in memory by where application code can execute and where it cannot. When a malicious worm attempts to insert code in the buffer, the processor disables code execution, preventing damage or worm propagation. Replacing older computers with Execute Disable Bit enabled systems can halt worm attacks, reducing the need for virus related repair.

Intel Virtualization Technology (Enabled)

When disabled, a VMM cannot utilize the additional hardware capabilities provided by Vandor Pool Technology.

Power Technology (Energy Efficient)

Use this item to control the Energy mode of the processor.

Press <Esc> to return to the Advanced Menu page.

► SATA Configuration

Use this item to show the information of USB configuration.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Advanced		
SATA Configuration		Select IDE/AHCI
SATA Mode	[AHCI Mode]	→ ← :Select Screen ↑↓:Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit
mSATA	Not Present	
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

SATA Mode (AHCI Mode)

Use this item to select SATA mode.

mSATA (Not Present)

This motherboard supports one mSATA channel, each channel allows one mSATA device to be installed. Use this item to configure each device on the mSATA channel.

Press <Esc> to return to the Advanced Menu page.

► USB Configuration

Use this item to show the information of USB configuration.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Advanced		
USB Configuration		USB Support Parameters
All USB Devices	[Enabled]	→ ← :Select Screen ↑ ↓ :Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit
Legacy USB Support	[Enabled]	
XHCI Mode	[Enabled]	
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

All USB Devices (Enabled)

Use this item to enable or disable all USB devices.

Legacy USB Support (Enabled)

Use this item to enable or disable support for legacy USB devices.

XHCI Mode (Enabled)

Use this item to enable or disable USB XHCI mode.

Press <Esc> to return to the Advanced Menu page.

Chipset Menu

The chipset menu items allow you to change the settings for the SoC chip and other system.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.						
Main	Advanced	Chipset	Tweak	Boot	Security	Exit
<ul style="list-style-type: none"> ▶ SoC Configuration ▶ TXE Information 		SoC Parameters → ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit				
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.						

► SoC Configuration

Scroll to this item and press <Enter> and view the following screen:

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Chipset		
SoC Configuration		Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device.
DVMT Pre-Allocated	[64M]	
DVMT Total Gfx Mem	[256MB]	
Restore AC Power Loss	[Power Off]	
Audio Configuration		→ ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Azalia HD Audio	[Enabled]	
Azalia Internal HDMI Codec	[Enabled]	
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

DVMT Pre-Allocated (64M)

This item is used to select DVMT 5.0 Pr-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device.

DVMT Total Gfx Mem (256MB)

This item shows the information of DVMT 5.0 and Graphic memory size used by the Internal Graphics Device.

Restore AC Power Loss (Power Off)

This item enables your computer to automatically restart or return to its operating status.

Azalia HD Audio (Enabled)

This item enables or disables Azalia HD Audio.

Azalia Internal HDMI Codec (Enabled)

This item enables or disables Azalia Internal HDMI Codec.

Press <Esc> to return to the Chipset Menu page.

► TXE Information

Scroll to this item and press <Enter> and view the following screen:

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Chipset		
TXE Information		Enable/Disable TXE Firmware
Sec RC Version	00.05.00.00	→ ← :Select Screen ↑ ↓ :Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit
TXE FW Version	01.01.00.1089	
TXE Mode	[Enabled]	
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

Sec RC Version (00.05.00.00)

This item shows the Sec Reference Code Version.

TXE FW Version (01.01.00.1089)

This item shows the TXE Firmware Version.

TXE Mode (Enabled)

This is TXE mode control item, it is used to enable or disable the TXE firmware.

Tweak Menu

This page enables you to set the clock speed and system bus for your system. The clock speed and system bus are determined by the kind of processor you have installed in your system.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Main	Advanced	Chipset
Tweak	Boot	Security Exit
Tweak		
CPU Frequency	83.3 MHz	
CPU Ratio	19	
Intel(R) Celeron(R) CPU N2808 @ 1.58GHz		
CPU Speed	1.58 GHz	
Memory Frequency	1333 MHz	
Total Memory	4096 MB (LPDDR3)	
		→ ← :Select Screen ↑ ↓ :Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

CPU Frequency (83.3 MHz)

This item shows the information of the CPU frequency.

CPU Ratio (19)

This item shows the information of the CPU Ratio.

Intel(R) Celeron(R) CPU N2808 @ 1.58GHz

This is display-only field and displays the information of the CPU installed in your computer.

CPU Speed (1.58 GHz)

This item shows the processor speed.

Memory Frequency (1333 MHz)

This item shows the memory frequency.

Total Memory (4096 MB (LPDDR3))

This item shows the total memory.

Boot Menu

This page enables you to set the keyboard Numlock State.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Main	Advanced	Chipset Tweak Boot Security Exit
Boot Configuration		Windows 7 or other OS: Boot policy for legacy OS
Operation System Select	[Windows 8.x]	
Launch Network OpROM	[Disabled]	
Fast Boot	[Disabled]	Windows 8.x: Boot policy for UEFI OS without Compatibility Support Module (CSM)
Bootup Numlock State	[On]	
Quiet Boot	[Enabled]	
Boot Mode Select	[UEFI]	Manual: User customized CSM parameters & boot policy
Set Boot Priority		
Boot Option #1	[Hard Disk : Windows...]	
Boot Option #2	[CD/DVD]	
Boot Option #3	[USB/Floppy]	
Boot Option #4	[USB CD/DVD]	
Boot Option #5	[USB Hard Disk]	
Boot Option #6	[USB Flash: UEFI:J...]	
Boot Option #7	[Network]	
►UEFI Hard Disk Drive Priorities		
►UEFI USB Flash Drive Priorities		
→ ← :Select Screen ↑ ↓ :Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit		
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

Operation System Select (Windows 8.x)

This item is used to select the operation system.

Launch Network OpROM (Disabled)

This item enables or disables launch PXE Option ROM.

Fast Boot (Disabled)

This item enables or disables the fast boot.

Bootup Numlock State (On)

This item enables you to select Numlock state.

Quiet Boot (Enabled)

This item enables or disables the quiet boot.

Boot Mode Select (UEFI)

Use this item to select boot mode.

Boot Option #1~7

These items show the boot priorities and can be used to set the boot priorities of various device categories.

UEFI Hard Disk Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing UEFI Boot drive. Press <Enter> to view the submenu.

UEFI USB Flash Drive Priorities

This item enables you to specify the sequence of loading the operating system from the installing UEFI USB Flash drive. Press <Enter> to view the submenu.

Security Menu

This page enables you to set setup administrator password and user password.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.			
Main	Advanced	Chipset	Tweak Boot Security Exit
Administrator Password Status	Not Installed	Set Administrator Password	
User Password Status	Not Installed		
Administrator Password		→ ← : Select Screen ↑ ↓ : Select Item Enter : Select +/- : Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
► Secure Boot menu			
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.			

Administrator Password Status (Not Installed)

This item shows administrator password installed or not.

User Password Status (Not Installed)

This item shows user password installed or not.

► Secure Boot menu

Scroll to this item and press <Enter> and view the following screen:

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
		Security
System Mode	Setup	Secure Boot can be enabled if 1. System running in User mode with enrolled Platform Key(PK) 2. CSM function is disabled
Secure Boot	Not Active	
Secure Boot	[Enabled]	
Secure Boot Mode	[Standard]	
		→ ← :Select Screen ↑ ↓ :Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

System Mode (User)

This item shows system of secure boot (can be setup or user).

Secure Boot (Active/Enabled)

This item shows the active state of secure boot.

Secure Boot Mode (Standard)

This item is used to select secure boot mode, when you select standard mode, secure boot policy is fixed; when you select custom mode, the image execution policy and secure boot key databases are changeable.

Exit Menu

This page enables you to set the keyboard Numlock State.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.	
Main	Advanced Chipset Tweak Boot Security Exit
Save Changes and Exit Discard Changes and Exit Save Changes and Reset Discard changes and Reset Save Options Save Changes Discard Changes Restore Defaults Save as User Defaults Restore User Defaults Boot Override Windows Boot Manager UEFI: JetFlashTS4GJFV20 0.00(FAT32)	Exit system setup after saving the changes. → ← :Select Screen ↑ ↓ :Select Item Enter : Select +/- : Change Opt. F1:General Help F2:Previous Values F3:Optimized Defaults F4:Save & Exit ESC:Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.	

Save Changes and Exit

This item enables you to exit the system setup after saving the changes.

Discard Changes and Exit

This item enables you to exit the system setup without saving any changes.

Save Changes and Reset

This item enables you to reset the system setup after saving the changes.

Discard Changes and Reset

This item enables you to reset the system setup without saving any changes.

Save Options

This item enables you to save the options that you have made.

Save Changes

This item enables you to save the changes that you have made.

Discard Changes

This item enables you to discard any change that you have made.

Restore Defaults

This item enables you to restore the system defaults.

Save as User Defaults

This item enables you to save the changes that you have made as user defaults.

Restore as User Defaults

This item enables you to restore the user defaults.

Boot Override

Use this item to select the boot device.

Updating the BIOS

You can download and install updated BIOS for this motherboard from the manufacturer's Website. New BIOS provides support for new peripherals, improvements in performance, or fixes for known bugs. Install new BIOS as follows:

- 1 If your motherboard has a BIOS protection jumper, change the setting to allow BIOS flashing.
- 2 If your motherboard has an item called Firmware Write Protect in Advanced BIOS features, disable it. (Firmware Write Protect prevents BIOS from being overwritten.)
- 3 Prepare a bootable device or create a bootable system disk. (Refer to Windows online help for information on creating a bootable system disk.)
- 4 Download the Flash Utility and new BIOS file from the manufacturer's Web site. Copy these files to the bootable device.
- 5 Turn off your computer and insert the bootable device in your computer. (You might need to run the Setup Utility and change the boot priority items on the Advanced BIOS Features Setup page, to force your computer to boot from the bootable device first.)
- 6 At the C:\ or A:\ prompt, type the Flash Utility program name and the file name of the new BIOS and then press <Enter>. Example: AFUDOS.EXE 040706.ROM
- 7 When the installation is complete, remove the bootable device from the computer and restart your computer. If your motherboard has a Flash BIOS jumper, reset the jumper to protect the newly installed BIOS from being overwritten. The computer will restart automatically.

Chapter 3

Using the Motherboard Software

Installing the Windows OS

There are two ways to install the Windows OS:

1. Install Windows OS via Windows official DVD.
2. Install Windows OS via USB flash drive.
 - a) Create an ISO file from the Windows 8.1 DVD.
 - b) Download the **Windows 7 USB/DVD Download Tool** from Microsoft and install it. Please refer to the link:
http://www.microsoftstore.com/store/msusa/html/pbPage.Help_Win7_usbdvd_dwnTool.

This free program from Microsoft properly formats your flash drive and then copies the contents of the Windows 8.1 installation ISO file to the flash drive.


- c) Boot from the USB device that you just created to start the Windows 8.1 installing process.



You need to change the booting priority in BIOS in order to boot from USB device. Enter into BIOS and select the Boot in menu (or press the hotkey F7), set USB drive as the first booting priority.

Drivers auto-installing under Windows 8.1

The auto-install DVD-ROM makes it easy for you to install the drivers and software. The support software DVD-ROM disc loads automatically under Windows 8.1. When you insert the DVD-ROM disc in the DVD-ROM drive, the auto-run feature will automatically bring up the installation screen.



Information:

Displays the path for all software and drivers available on the disk.


Click the “Setup”

button to select and run the software installation program.

Running Setup

Follow these instructions to install device drivers and software for the motherboard:


1. Click **Setup**. The installation program begins:




The following screens are examples only. The screens and driver lists will be different according to the motherboard you are installing.

The motherboard identification is located in the upper left-hand corner.

2. Click **Next**. The following screen appears:



3. Check the box next to the items you want to install. The default options are recommended.
4. Click **Next** to run the Installation Wizard. An item installation screen appears:



5. Follow the instructions on the screen to install the items.




Drivers and software are automatically installed in sequence. Follow the onscreen instructions, confirm commands and allow the computer to restart a few times to complete the installation.

Windows 8.1 will show the following screen after system restart, you must select “Desktop” in the bottom left to install the next driver.



Windows 8.1 will appear below UAC (User Account Control) message after the system restart. You must select “Yes” to install the next driver. Continue this process to complete the drivers installation.



Manual Installation

If the auto-install DVD-ROM does not work on your system, you can still install drivers through the file manager for your OS (for example, Windows Explorer). Look for the chipset and motherboard model, and then browse to the directory and path to begin installing the drivers. Most drivers have a setup program (SETUP.EXE) that automatically detects your operating system before installation. Other drivers have the setup program located in the operating system subfolder.

If the driver you want to install does not have a setup program, browse to the operating system subfolder and locate the readme text file (README.TXT or README.DOC) for information on installing the driver or software for your operating system.

ECS Utility Software (Intelligent EZ Utility)

ECS Intelligent EZ Utility provides friendly interfaces under Windows O.S., which make your computing more easily and conveniently.



These software(s) are subject to change at anytime without prior notice. Please refer to the support disk for available software.


eDLU

ECS eDLU utility makes updating drivers fast and easy. eDLU saves time and hassle by listing all the latest drivers online. Just select the one you prefer and start to download and install the drivers.



eBLU

ECS eBLU utility makes BIOS update faster and easier. eBLU will list the latest BIOS with a default check-mark. Click "install" button to install.



Microsoft .NET Framework 3.5 is required.

Windows 8.1 OS Recovery

If you purchased LIVA product with OS pre-loaded and having problems with the system, you can try to refresh, reset or restore it. The following instructions of OS recovery are quoted from Microsoft® website. For more detail and information, please refer to the link: http://windows.microsoft.com/en-us/windows-8/_restore-refresh-reset-pc

To refresh your PC



Warning:

Apps you installed from websites and DVDs will be removed. Apps that came with your PC and apps you installed from the Windows Store will be reinstalled. Windows puts a list of removed apps on your desktop after refreshing your PC.

1. Swipe in from the right edge of the screen, tap **Settings**, and then tap **Change PC settings**. (If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, click **Settings**, and then click **Change PC settings**.)
2. Tap or click **Update and recovery**, and then tap or click **Recovery**.
3. Under **Refresh your PC without affecting your files**, tap or click **Get started**.
4. Follow the instructions on the screen.

To reset your PC



Warning:

All of your personal files will be deleted and your settings will be reset. All apps that you installed will be removed. Only apps that came with your PC will be reinstalled.

1. Swipe in from the right edge of the screen, tap **Settings**, and then tap **Change PC settings**. (If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, click **Settings**, and then click **Change PC settings**.)
2. Tap or click **Update and recovery**, and then tap or click **Recovery**.
3. Under **Remove everything and reinstall Windows**, tap or click **Get started**.
4. Follow the instructions on the screen.



Note:

You'll be asked to choose whether you want to erase data quickly or thoroughly. If you choose to erase data quickly. Some data might be recoverable using special software. If you choose to erase data thoroughly, this will longer but it makes recovering data less likely.

To restore your PC to an earlier point in time



Note:

Windows automatically creates a restore point when you install desktop apps and new Windows updates, if the last restore point is older than 7 days. you can also create a restore point manually at any time.

1. Swipe in from the right edge of the screen, and then tap **Search**. (If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, and then click **Search**.)
2. Enter **Control Panel** in the search box, and tap or click **Control Panel**.
3. Enter **Recovery** in the Control Panel search box, and then tap or click **Recovery**.
4. Tap or click **Open System Restore**, and then follow the instructions.

RMA Service for OS recovery



Note:

LIVA product will be reformatted to the original factory configuration after repair. ECS is not liable to restore or transfer the customer's own responsibility to back up the data and information stored in the hard drive before provide the defective LIVA products for repair service.

Memo

Chapter 4

Trouble Shooting

Troubleshooting and problem solution

After assembling the PC for the first time you may experience some start up problems. Before calling for technical support or returning for warranty, this chapter may help to address some of the common questions using some basic troubleshooting tips.

a) Boot up failed.

1. Use the specified adapter provided by ECS.
2. Check whether the adapter has been plugged in.
3. Check the connection between adapter and the system.
4. Check that the power button can be pushed normally. If it is successfully powered on, the green light from LED will show up.
5. If the boot up problem still exists after these checking steps, please turn to local dealer or repair center for further customer service.

b) Black screen or no image is displayed on the monitor.


1. Check whether the monitor has been turned on or works normally on other system.
2. Check whether the system has been powered on successfully.

3. Check the cable is securely inserted into rear IO ports(VGA/HDMI) and also at monitor side(VGA/HDMI).


4. If the display problem still exists after checking steps, please turn to local dealer or repair center for further customer service.

c) Display Error

1. Check whether the driver is correctly installed in “Device Manager”. If there is yellow mark or unknown devices message shown in the list, please reinstall the driver via LIVA official Driver DVD or ECS official website.



2. Adjust the screen to the best resolution to get better using experience.



d) Wire LAN connecting failed.

1. Check whether the LAN driver is correctly installed in “Device Manager”. If there is yellow mark or unknown devices message shown in the list, please reinstall the driver via LIVA official Driver DVD or ECS official website.

2. Ensure the LAN cable is securely inserted to the RJ45 port and the LED light flashes normally.

3. Check IP address.


4. If the LAN connection problem still exists after these checking steps, please turn to local dealer or repair center for further customer service.

e) Wireless LAN connecting failed

1. Check whether the WLAN card driver is correctly installed in “Device Manager”. If there is yellow mark or unknown devices message shown in the list, please reinstall the driver via LIVA official Driver DVD or ECS official website.
2. Check the WIFI in your working area is well functional and has good reception.
3. If the WIFI connection problem still exists after these checking steps, please turn to local dealer or repair center for further customer service.

f) No sound from audio combo jack

1. Check whether the audio driver is correctly installed in “Device Manager”. If there is yellow mark or unknown devices message shown in the list, please reinstall the driver via LIVA official Driver DVD or ECS official website.
2. After connecting the speaker or header phone, adjust audio setting in Control panel> Hardware and sound.



Note: Due to chipset limitation, the mic function of audio codec AL282 can be only compatibel to iPhone devices.

3. If the audio problem still exists after these checking steps, please turn to local dealer or repair center for further customer service.

Memo